

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

002090" ST 98560




Fig. 1

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

002090" ST 98560

Field A (X coordinate)		
Breakpoint	Interval	Bitmap
01	001	000
03	010	001
07	011	101
0E	100	001
17	101	011
1C	110	010
1F	111	000
Field B (Y coordinate)		
Breakpoint	Interval	Bitmap
03	001	000
04	010	100
09	011	110
0B	100	100
13	101	101
1B	110	100
1F	111	000

Fig. 2

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

002090" 5T 92550




Fig. 3

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

002000" 51193550

First Step - Field A X-axis	
Breakpoint	Pointer to the next step
07	If >, then 1
	If <, then 0
First Step - Field B Y-axis	
Breakpoint	Pointer to the next step
09	If >, then 1
	If <, then 0

Fig. 4

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

0958615 "060200

Second Step - Field A X-axis		
Pointer from 1st module	Breakpoint	Pointer to 3rd step
1	17	If >, then 11
		If <, then 10
0	01	If >, then 01
		If <, then 00
Second Step - Field B Y-axis		
Pointer from 1st module	Breakpoint	Pointer to 3rd step
1	13	If >, then 11
		If <, then 10
0	03	If >, then 01
		If <, then 00

Fig. 5

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

053615-060200

Third Step - Field A X-axis		
Pointer from 2nd module	Breakpoint	Interval Number
11	1C	If >, then 111
		If <, then 110
10	0E	If >, then 101
		If <, then 100
01	03	If >, then 011
		If <, then 010
00	None	Must be 001
Third Step - Field B Y-axis		
Pointer from 2nd module	Breakpoint	Interval Number
11	1B	If >, then 111
		If <, then 110
10	0B	If >, then 101
		If <, then 100
01	04	If >, then 011
		If <, then 010
00	None	Must be 001

Fig. 6

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		




Fig. 7

002090" ST 98560

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		




Fig. 8a




Fig. 8b

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		




Fig. 9